




Baureihe 88 MD – auswärts



Baureihe 88 MD – einwärts



Bodenanschlüsse – Baureihe 88 MD



Baureihe 88 MD – einwärts

<p>Bandseite Standard</p>	<p>Technical drawing of the Aldra 88 MD inward-opening window handle mechanism, Bandseite Standard view. The drawing shows a cross-section of the handle assembly with dimensions: 92, 182, 90, 88, 56, 105, 21, 88172, and 88276.</p>
<p>Schlosseite Standard</p>	<p>Technical drawing of the Aldra 88 MD inward-opening window handle mechanism, Schlosseite Standard view. The drawing shows a cross-section of the handle assembly with dimensions: 90, 182, 92, 88, 53,5, 55, 34,5, 21, 105, 56, 88172, and 88276.</p>